


Concrete Sidewalk – Removal and Replacement



1. Layout and mark all areas of repair.
2. Demolish and remove areas to be repaired to the nearest joint or saw cut. Dispose of all debris offsite.
3. Cut walls of demolition to produce vertical edges.
4. Install forms as necessary to retain and support concrete.
5. Roll existing subgrade materials to achieve maximum density.
6. Install 4" depth 3,500 psi air entrained concrete and finish level with top adjacent concrete. Install expansion joint material every 30 linear feet on center and crack control joints every 5 linear feet on center. Light-broom finish concrete surface to ensure traction.
7. Apply curing compound and/or provide protection against elements as necessary to promote curing of new installation.
8. Remove forms and backfill adjacent disturbed areas as needed using onsite materials.

